


Zestawy równoległe

ZH...



n x kW	Wymiary szafy sterującej [mm] i masa [kg]									
	sterowanie kaskadowe					sterowanie przetwornicą				
	a	b	h	h _i	masa	a	b	h	h _i	masa
5x0,37	600	210	1600	600	31	1000	300	1600	800	108
5x0,55										
5x0,75										
5x1,1										
5x1,5										
5x2,2										
5x3,0	800	300	1600	1000	68	1000	300	1600	800	108
5x4,0										
5x5,5										
5x7,5	1000	400	1800	-	161	1200	400	2000	1000	113
5x11,0					162				1000	115
5x15,0					164				1000	120
5x18,5					202				1000	190
5x22,0	1200	400	1800	-	203	1600	400	2000	-	200
5x30,0					204					210
6x0,37	600	210	1600	600	32	1000	300	1600	800	108
6x0,55										
6x0,75										
6x1,1										
6x1,5										
6x2,2										
6x3,0	800	300	1600	1000	69	1000	300	1600	800	108
6x4,0										
6x5,5										
6x7,5	1000	400	1800	-	163	1200	400	2000	1000	115
6x11,0					164				1000	117
6x15,0					165				1000	124
6x18,5					168				1000	200
6x22,0	1200	400	1800	-	204	1600	400	2000	-	205
6x30,0					206					210
6x30,0	1200	400	1800	-	208	1600	400	2000	-	210
6x30,0					208					210